

HOW TO PAINT A FRONT DOOR

INSTRUCTIONS

SHOPPING LIST

- Corotech Command Paint
- Painter's Tape
- Angular Brush
- Handy Paint Pail
- Wooster Big Green Mini Roller
- Atmosphere Drop Cloth

PREP

1. Select your paint. We recommend Corotech Command Paint for faster drying time.
2. Remove any non-permanent hardware.
3. If there is peeling paint, use a paint scraper to remove loose bits, being careful to wipe away debris.
4. Clean with TSP, then rinse and let dry completely.
5. Cover permanent hardware like hinges using painter's tape.

SAND & PRIME

1. Sand door very lightly with fine-grit sandpaper to rough up surface and wipe away dust with a dry cloth.
2. If your door has been previously painted or is material like wood, check with our Paint Shop experts as you may need to prime first.

PAINT: USING COMMAND*

1. Using your chosen paint colour, apply with a brush and roller. Use the angled brush to paint in the tight angles, trim any windows or hardware, then roll the larger areas.
2. Once the door is dry for a minimum of 1 hour apply the 2nd coat.
3. The second coat will be dry in 1 hour and the door can be closed. Allow 24 hours before high usage.

*Instructions may differ pending Benjamin Moore product chosen. Please consult a sales associate.

IMPORTANT! High humidity and cool temperatures will result in longer drying times.

MORE QUESTIONS? Contact your local **Benjamin Moore Paint Shop** and our expert staff will be happy to help. Visit our website at paintshop.ca to find a location near you.

