HOW TO PAINT FURNITURE INSTRUCTIONS

SHOPPING LIST

- Advance Interior Paint
- Stix Primer
- TSP Cleaner

- 4" Foam or Microfiber Roller
- Angular Brush
- Painters' Tape

- Medium Grit Sandpaper
- 🗌 Light Grit Sandpaper
- Drop Cloth

PREP

- 1. Remove hardware and store in a safe place.
- 2. Find a workspace to paint your furniture and cover with a dropcloth if necessary.
- 3. Clean all surfaces using TSP. Wipe down with a damp cloth.
- 4. Sand lightly. Use a medium grit sandpaper (100- to 150-grit) to roughen up the surface. This will give the surface extra "teeth" to grab hold of the paint as it's being applied.
- 5. Clean surfaces again, using a damp cloth or dry tack cloth, wiping away any new dust.

PRIME

- 1. Prime with Stix Primer. It will turn any new or unknown surface into a blank canvas. Wait 24 hours, until dry.
- 2. Lightly sand with 220-grit sandpaper to smooth out drips or pools and give the surface extra grip for the **Advance Interior Paint** to bond.

PAINT

- 1. Using **Advance Interior Paint**, apply the first coat. Cut in on uneven surfaces and corners with an angled brush. On flat surfaces, use a 4" foam or microfiber roller. Let the paint dry completely for 24 hours.
- 2. Once the paint is fully dry, sand with 220-grit sandpaper, again to encourage adhesion. Then, wipe away any new dust with a slightly damp cloth.
- 3. Apply second coat. Let the paint dry for 24 hours before reattaching hardware.
- 4. Reattach your hardware and enjoy your handywork! After reinstalling hardware, please allow 5 7 days for Advance to fully cure.

MORE QUESTIONS? Contact your local **Benjamin Moore Paint Shop** and our expert staff will be happy to help. Visit our website at **paintshop.ca** to find a location near you.

